
JIS
ASEC
print 2-D codes
M1CLEVER
(AS/400DataQ)
Emergency level 1
Emergency level 2
ftp
dq_reader
pmc_dqreader
dq2dbus.cfg
as400dirq
(DirQ)
as400dirq
pmc_dirq
as400dirq.cfg
as400dirq
(HistoryDirQ)
asecdirq
(DirQ)
asecdirq
pmc_dirq
asecdirq.cfg
asecdirq
(HistoryDirQ)
twodcodedirq
(DirQ)
twodcodedirq
pmc_dirq
twodcodedirq.cfg
twodcodedirq
(HistoryDirQ)
as400dq2xml
pmc_alien2xml
as400dq2xml.cfg
asec2xml
pmc_alien2xml
asec2xml.cfg
twodcode2xml
pmc_alien2xml
twodcode2xml.cfg
as400xmldirq
(DirQ)
as400xmldirq
pmc_dirq
as400dirq.cfg
as400xmldirq
(HistoryDirQ)
asecxmldirq
(DirQ)
asecxmldirq
pmc_dirq
asecxmldirq.cfg
asecxmldirq
(HistoryDirQ)
twodcodexmldirq
(DirQ)
twodcodexmldirq
pmc_dirq
twodcodexmldirq.cfg
twodcodexmldirq
(HistoryDirQ)
dupcheck
pmc_dupcheck
pmc_dupl.cfg
xml2krnl
pmc_xml2alien
dq2dbus.cfg
CLEVER Kernel server
krnldirq
(DirQ)
krnldirq
pmc_dirq
krnldirq.cfg
krnldirq
(HistoryDirQ)
kernel_sender
pmc_kernelsender
dbus2krnl.cfg
CLEVER Kernel
plc_krnl
plc_krnl_proj.cfg
CLEVER workstation
CLEVER Client Workstation
plc_client
plc_client_ID.cfg
scan
Built sheet with 2-D barcode
Emergency level 3
Local kernel chain
plc_krnl, pmc system
plc_krnl_proj.cfg, pmc configs